

RESEAU 3

Station: ANDENNE

Fréquence: 107.4 MHz

Position: 5°E05'40" 50°N28'14"

Puissance: 200 W

Hauteur de l'antenne au-dessus du sol: 43 m

Diagramme directionnel de l'antenne:

0: 06	60: 07	120: 04	180: 00	240: 00	300: 01
10: 06	70: 06	130: 03	190: 00	250: 00	310: 02
20: 06	80: 06	140: 03	200: 00	260: 00	320: 03
30: 06	90: 06	150: 02	210: 00	270: 00	330: 03
40: 07	100: 06	160: 01	220: 00	280: 00	340: 04
50: 07	110: 05	170: 01	230: 00	290: 01	350: 05

Station: ARLON

Fréquence: 101.0 MHz

Position: 5°E49'03" 49°N41'17"

Puissance: 100 W

Hauteur de l'antenne au-dessus du sol: 20 m

Diagramme directionnel de l'antenne:

0: 06	60: 06	120: 03	180: 00	240: 00	300: 03
10: 06	70: 06	130: 02	190: 00	250: 00	310: 03
20: 07	80: 06	140: 01	200: 00	260: 00	320: 04
30: 07	90: 05	150: 01	210: 00	270: 01	330: 05
40: 07	100: 04	160: 00	220: 00	280: 01	340: 06
50: 06	110: 03	170: 00	230: 00	290: 02	350: 06

Station: ATH

Fréquence: 95.4 MHz

Position: 3°E45'30" 50°N37'28"

Puissance: 500 W

Hauteur de l'antenne au-dessus du sol: 19 m

Diagramme directionnel de l'antenne:

0: 03	60: 16	120: 16	180: 16	240: 13	300: 01
10: 05	70: 16	130: 16	190: 16	250: 10	310: 00
20: 07	80: 16	140: 16	200: 16	260: 07	320: 00
30: 10	90: 16	150: 16	210: 16	270: 05	330: 00
40: 13	100: 16	160: 16	220: 16	280: 03	340: 01
50: 16	110: 16	170: 16	230: 16	290: 02	350: 02

Station: BASTOGNE

Fréquence: 106.7 MHz

Position: 5°E44'00" 50°N01'00"

Puissance: 1000 W

Hauteur de l'antenne au-dessus du sol: 36 m

Diagramme directionnel de l'antenne:

0: 07	60: 04	120: 00	180: 00	240: 01	300: 06
10: 06	70: 03	130: 00	190: 00	250: 02	310: 06
20: 06	80: 03	140: 00	200: 00	260: 03	320: 06
30: 06	90: 02	150: 00	210: 00	270: 03	330: 06
40: 06	100: 01	160: 00	220: 00	280: 04	340: 07
50: 05	110: 01	170: 00	230: 01	290: 05	350: 07

RESEAU 3

Station: BEAURAING

Fréquence: 107.5 MHz

Position: 4°E56'20" 50°N05'22"

Puissance: 100 W

Hauteur de l'antenne au-dessus du sol: 15 m

Diagramme directionnel de l'antenne:

0: 00	60: 00	120: 00	180: 00	240: 00	300: 00
10: 00	70: 00	130: 00	190: 00	250: 00	310: 00
20: 00	80: 00	140: 00	200: 00	260: 00	320: 00
30: 00	90: 00	150: 00	210: 00	270: 00	330: 00
40: 00	100: 00	160: 00	220: 00	280: 00	340: 00
50: 00	110: 00	170: 00	230: 00	290: 00	350: 00

Station: BINCHE

Fréquence: 106.7 MHz

Position: 4°E10'35" 50°N24'43"

Puissance: 300 W

Hauteur de l'antenne au-dessus du sol: 30 m

Diagramme directionnel de l'antenne:

0: 06	60: 01	120: 00	180: 00	240: 04	300: 07
10: 05	70: 01	130: 00	190: 01	250: 05	310: 07
20: 04	80: 00	140: 00	200: 01	260: 06	320: 07
30: 03	90: 00	150: 00	210: 02	270: 06	330: 06
40: 03	100: 00	160: 00	220: 03	280: 06	340: 06
50: 02	110: 00	170: 00	230: 03	290: 06	350: 06

Station: BOUGE

Fréquence: 104.3 MHz

Position: 4°E53'14" 50°N28'19"

Puissance: 4000 W

Hauteur de l'antenne au-dessus du sol: 30 m

Diagramme directionnel de l'antenne:

0: 06	60: 03	120: 00	180: 00	240: 02	300: 06
10: 06	70: 03	130: 00	190: 00	250: 03	310: 06
20: 06	80: 02	140: 00	200: 00	260: 03	320: 06
30: 06	90: 01	150: 00	210: 00	270: 04	330: 07
40: 05	100: 01	160: 00	220: 01	280: 05	340: 07
50: 04	110: 00	170: 00	230: 01	290: 06	350: 07

Station: BOUILLON

Fréquence: 88.3 MHz

Position: 5°E04'42" 49°N48'03"

Puissance: 5000 W

Hauteur de l'antenne au-dessus du sol: 40 m

Diagramme directionnel de l'antenne:

0: 20	60: 20	120: 20	180: 03	240: 03	300: 20
10: 20	70: 20	130: 20	190: 01	250: 06	310: 20
20: 20	80: 20	140: 15	200: 00	260: 09	320: 20
30: 20	90: 20	150: 10	210: 00	270: 10	330: 20
40: 20	100: 20	160: 09	220: 00	280: 15	340: 20
50: 20	110: 20	170: 06	230: 01	290: 20	350: 20

RESEAU 3

Station: BRAINE LE COMTE

Fréquence: 106.7 MHz

Position: 4°E10'45" 50°N36'27"

Puissance: 100 W

Hauteur de l'antenne au-dessus du sol: 40 m

Diagramme directionnel de l'antenne:

0: 07	60: 00	120: 00	180: 00	240: 00	300: 00
10: 06	70: 00	130: 00	190: 00	250: 00	310: 00
20: 06	80: 00	140: 00	200: 00	260: 00	320: 00
30: 06	90: 00	150: 00	210: 00	270: 00	330: 00
40: 06	100: 00	160: 00	220: 00	280: 00	340: 07
50: 00	110: 00	170: 00	230: 00	290: 00	350: 07

Station: BRUXELLES

Fréquence: 100.0 MHz

Position: 4°E20'39" 50°N49'22"

Puissance: 5000 W

Hauteur de l'antenne au-dessus du sol: 119 m

Diagramme directionnel de l'antenne:

0: 00	60: 00	120: 00	180: 00	240: 00	300: 00
10: 00	70: 00	130: 00	190: 00	250: 00	310: 00
20: 00	80: 00	140: 00	200: 00	260: 00	320: 00
30: 00	90: 00	150: 00	210: 00	270: 00	330: 00
40: 00	100: 00	160: 00	220: 00	280: 00	340: 00
50: 00	110: 00	170: 00	230: 00	290: 00	350: 00

Station: CHARLEROI

Fréquence: 100.0 MHz

Position: 4°E26'03" 50°N26'50"

Puissance: 500 W

Hauteur de l'antenne au-dessus du sol: 20 m

Diagramme directionnel de l'antenne:

0: 00	60: 00	120: 00	180: 00	240: 00	300: 00
10: 00	70: 00	130: 00	190: 00	250: 00	310: 00
20: 00	80: 00	140: 00	200: 00	260: 00	320: 00
30: 00	90: 00	150: 00	210: 00	270: 00	330: 00
40: 00	100: 00	160: 00	220: 00	280: 00	340: 00
50: 00	110: 00	170: 00	230: 00	290: 00	350: 00

Station: CHIMAY

Fréquence: 106.6 MHz

Position: 4°E19'12" 50°N03'00"

Puissance: 100 W

Hauteur de l'antenne au-dessus du sol: 26 m

Diagramme directionnel de l'antenne:

0: 05	60: 07	120: 05	180: 01	240: 00	300: 01
10: 06	70: 07	130: 04	190: 00	250: 00	310: 01
20: 06	80: 06	140: 03	200: 00	260: 00	320: 02
30: 06	90: 06	150: 03	210: 00	270: 00	330: 03
40: 06	100: 06	160: 02	220: 00	280: 00	340: 03
50: 07	110: 06	170: 01	230: 00	290: 00	350: 04

RESEAU 3

Station: CINEY

Fréquence: 106.9 MHz

Position: 5°E06'07" 50°N17'52"

Puissance: 500 W

Hauteur de l'antenne au-dessus du sol: 60 m

Diagramme directionnel de l'antenne:

0: 04	60: 00	120: 00	180: 01	240: 06	300: 07
10: 03	70: 00	130: 00	190: 02	250: 06	310: 06
20: 03	80: 00	140: 00	200: 03	260: 06	320: 06
30: 02	90: 00	150: 00	210: 03	270: 06	330: 06
40: 01	100: 00	160: 00	220: 04	280: 07	340: 06
50: 01	110: 00	170: 01	230: 05	290: 07	350: 05

Station: COUVIN

Fréquence: 104.4 MHz

Position: 4°E30'09" 50°N02'55"

Puissance: 630 W

Hauteur de l'antenne au-dessus du sol: 18 m

Diagramme directionnel de l'antenne:

0: 00	60: 00	120: 02	180: 06	240: 06	300: 03
10: 00	70: 00	130: 03	190: 06	250: 06	310: 03
20: 00	80: 00	140: 03	200: 06	260: 06	320: 02
30: 00	90: 00	150: 04	210: 07	270: 06	330: 01
40: 00	100: 01	160: 05	220: 07	280: 05	340: 01
50: 00	110: 01	170: 06	230: 07	290: 04	350: 00

Station: DINANT

Fréquence: 100.7 MHz

Position: 4°E56'40" 50°N16'02"

Puissance: 2000 W

Hauteur de l'antenne au-dessus du sol: 30 m

Diagramme directionnel de l'antenne:

0: 06	60: 06	120: 03	180: 00	240: 00	300: 02
10: 06	70: 06	130: 03	190: 00	250: 00	310: 03
20: 06	80: 06	140: 02	200: 00	260: 00	320: 03
30: 07	90: 06	150: 01	210: 00	270: 00	330: 04
40: 07	100: 05	160: 01	220: 00	280: 01	340: 05
50: 07	110: 04	170: 00	230: 00	290: 01	350: 06

Station: FRAMERIES

Fréquence: 93.9 MHz

Position: 3°E53'16" 50°N23'07"

Puissance: 630 W

Hauteur de l'antenne au-dessus du sol: 49 m

Diagramme directionnel de l'antenne:

0: 03	60: 01	120: 13	180: 16	240: 16	300: 16
10: 02	70: 02	130: 16	190: 16	250: 16	310: 16
20: 01	80: 03	140: 16	200: 16	260: 16	320: 13
30: 00	90: 05	150: 16	210: 16	270: 16	330: 10
40: 00	100: 07	160: 16	220: 16	280: 16	340: 07
50: 00	110: 10	170: 16	230: 16	290: 16	350: 05

RESEAU 3

Station: GEMBLOUX

Fréquence: 106.3 MHz

Position: 4°E41'12" 50°N34'51"

Puissance: 100 W

Hauteur de l'antenne au-dessus du sol: 38 m

Diagramme directionnel de l'antenne:

0: 00	60: 00	120: 00	180: 00	240: 00	300: 00
10: 00	70: 00	130: 00	190: 00	250: 00	310: 00
20: 00	80: 00	140: 00	200: 00	260: 00	320: 00
30: 00	90: 00	150: 00	210: 00	270: 00	330: 00
40: 00	100: 00	160: 00	220: 00	280: 00	340: 00
50: 00	110: 00	170: 00	230: 00	290: 00	350: 00

Station: GENAPPE

Fréquence: 107.7 MHz

Position: 4°E23'39" 50°N37'47"

Puissance: 400 W

Hauteur de l'antenne au-dessus du sol: 54 m

Diagramme directionnel de l'antenne:

0: 20	60: 20	120: 01	180: 06	240: 20	300: 20
10: 20	70: 15	130: 00	190: 09	250: 20	310: 20
20: 20	80: 10	140: 00	200: 10	260: 20	320: 20
30: 20	90: 09	150: 00	210: 15	270: 20	330: 20
40: 20	100: 06	160: 01	220: 20	280: 20	340: 20
50: 20	110: 03	170: 03	230: 20	290: 20	350: 20

Station: HUY

Fréquence: 104.1 MHz

Position: 5°E14'22" 50°N32'04"

Puissance: 1000 W

Hauteur de l'antenne au-dessus du sol: 18 m

Diagramme directionnel de l'antenne:

0: 02	60: 00	120: 00	180: 00	240: 00	300: 00
10: 02	70: 00	130: 00	190: 00	250: 00	310: 00
20: 00	80: 00	140: 00	200: 00	260: 00	320: 00
30: 00	90: 00	150: 00	210: 00	270: 00	330: 00
40: 00	100: 00	160: 00	220: 00	280: 00	340: 00
50: 00	110: 00	170: 00	230: 00	290: 00	350: 00

Station: JALHAY

Fréquence: 106.0 MHz

Position: 5°E54'45" 50°N34'53"

Puissance: 100 W

Hauteur de l'antenne au-dessus du sol: 35 m

Diagramme directionnel de l'antenne:

0: 07	60: 06	120: 01	180: 00	240: 00	300: 04
10: 07	70: 05	130: 01	190: 00	250: 01	310: 05
20: 07	80: 04	140: 00	200: 00	260: 01	320: 06
30: 06	90: 03	150: 00	210: 00	270: 02	330: 06
40: 06	100: 03	160: 00	220: 00	280: 03	340: 06
50: 06	110: 02	170: 00	230: 00	290: 03	350: 06

RESEAU 3

Station: JODOIGNE

Fréquence: 107.2 MHz

Position: 4°E52'55" 50°N43'30"

Puissance: 200 W

Hauteur de l'antenne au-dessus du sol: 32 m

Diagramme directionnel de l'antenne:

0: 06	60: 07	120: 04	180: 00	240: 00	300: 01
10: 06	70: 06	130: 03	190: 00	250: 00	310: 02
20: 06	80: 06	140: 03	200: 00	260: 00	320: 03
30: 06	90: 06	150: 02	210: 00	270: 00	330: 03
40: 07	100: 06	160: 01	220: 00	280: 00	340: 04
50: 07	110: 05	170: 01	230: 00	290: 01	350: 05

Station: LA LOUVIERE

Fréquence: 105.5 MHz

Position: 4°E12'56" 50°N28'25"

Puissance: 100 W

Hauteur de l'antenne au-dessus du sol: 35 m

Diagramme directionnel de l'antenne:

0: 06	60: 07	120: 04	180: 00	240: 00	300: 01
10: 06	70: 06	130: 03	190: 00	250: 00	310: 02
20: 06	80: 06	140: 03	200: 00	260: 00	320: 03
30: 06	90: 06	150: 02	210: 00	270: 00	330: 03
40: 07	100: 06	160: 01	220: 00	280: 00	340: 04
50: 07	110: 05	170: 01	230: 00	290: 01	350: 05

Station: LESSINES

Fréquence: 106.4 MHz

Position: 3°E50'50" 50°N43'03"

Puissance: 100 W

Hauteur de l'antenne au-dessus du sol: 25 m

Diagramme directionnel de l'antenne:

0: 00	60: 00	120: 00	180: 00	240: 00	300: 00
10: 00	70: 00	130: 00	190: 00	250: 00	310: 00
20: 00	80: 00	140: 00	200: 00	260: 00	320: 00
30: 00	90: 00	150: 00	210: 00	270: 00	330: 00
40: 00	100: 00	160: 00	220: 00	280: 00	340: 00
50: 00	110: 00	170: 00	230: 00	290: 00	350: 00

Station: LIEGE

Fréquence: 100.9 MHz

Position: 5°E33'58" 50°N38'05"

Puissance: 2000 W

Hauteur de l'antenne au-dessus du sol: 39 m

Diagramme directionnel de l'antenne:

0: 00	60: 00	120: 00	180: 00	240: 00	300: 00
10: 00	70: 00	130: 00	190: 00	250: 00	310: 00
20: 00	80: 00	140: 00	200: 00	260: 00	320: 00
30: 00	90: 00	150: 00	210: 00	270: 00	330: 00
40: 00	100: 00	160: 00	220: 00	280: 00	340: 00
50: 00	110: 00	170: 00	230: 00	290: 00	350: 00

RESEAU 3

Station: MALMEDY

Fréquence: 92.7 MHz

Position: 6°E01'00" 50°N26'10"

Puissance: 1000 W

Hauteur de l'antenne au-dessus du sol: 30 m

Diagramme directionnel de l'antenne:

0: 16	60: 05	120: 00	180: 10	240: 16	300: 16
10: 16	70: 03	130: 01	190: 13	250: 16	310: 16
20: 16	80: 02	140: 02	200: 16	260: 16	320: 16
30: 13	90: 01	150: 03	210: 16	270: 16	330: 16
40: 10	100: 00	160: 05	220: 16	280: 16	340: 16
50: 07	110: 00	170: 07	230: 16	290: 16	350: 16

Station: MARCHE

Fréquence: 101.2 MHz

Position: 5°E21'51" 50°N13'17"

Puissance: 100 W

Hauteur de l'antenne au-dessus du sol: 35 m

Diagramme directionnel de l'antenne:

0: 00	60: 00	120: 00	180: 00	240: 00	300: 00
10: 00	70: 00	130: 00	190: 00	250: 00	310: 00
20: 00	80: 00	140: 00	200: 00	260: 00	320: 00
30: 00	90: 00	150: 00	210: 00	270: 00	330: 00
40: 00	100: 00	160: 00	220: 00	280: 00	340: 00
50: 00	110: 00	170: 00	230: 00	290: 00	350: 00

Station: MOUSCRON

Fréquence: 106.8 MHz

Position: 3°E11'38" 50°N45'25"

Puissance: 160 W

Hauteur de l'antenne au-dessus du sol: 43 m

Diagramme directionnel de l'antenne:

0: 06	60: 06	120: 03	180: 00	240: 00	300: 02
10: 06	70: 06	130: 03	190: 00	250: 00	310: 03
20: 06	80: 06	140: 02	200: 00	260: 00	320: 03
30: 07	90: 06	150: 01	210: 00	270: 00	330: 04
40: 07	100: 05	160: 01	220: 00	280: 01	340: 05
50: 07	110: 04	170: 00	230: 00	290: 01	350: 06

Station: NEUFCHATEAU

Fréquence: 105.2 MHz

Position: 5°E26'10" 49°N50'24"

Puissance: 800 W

Hauteur de l'antenne au-dessus du sol: 30 m

Diagramme directionnel de l'antenne:

0: 00	60: 00	120: 04	180: 07	240: 06	300: 01
10: 00	70: 01	130: 05	190: 07	250: 05	310: 01
20: 00	80: 01	140: 06	200: 07	260: 04	320: 00
30: 00	90: 02	150: 06	210: 06	270: 03	330: 00
40: 00	100: 03	160: 06	220: 06	280: 03	340: 00
50: 00	110: 03	170: 06	230: 06	290: 02	350: 00

RESEAU 3

Station: NIVELLES

Fréquence: 89.9 MHz

Position: 4°E19'30" 50°N36'00"

Puissance: 200 W

Hauteur de l'antenne au-dessus du sol: 18 m

Diagramme directionnel de l'antenne:

0: 05	60: 09	120: 05	180: 01	240: 00	300: 01
10: 06	70: 09	130: 04	190: 00	250: 00	310: 01
20: 06	80: 06	140: 03	200: 00	260: 00	320: 02
30: 06	90: 06	150: 03	210: 00	270: 00	330: 03
40: 08	100: 06	160: 02	220: 00	280: 00	340: 03
50: 09	110: 06	170: 01	230: 00	290: 00	350: 04

Station: PHILIPPEVILLE

Fréquence: 105.7 MHz

Position: 4°E33'07" 50°N11'51"

Puissance: 100 W

Hauteur de l'antenne au-dessus du sol: 35 m

Diagramme directionnel de l'antenne:

0: 00	60: 00	120: 04	180: 07	240: 06	300: 01
10: 00	70: 01	130: 05	190: 07	250: 05	310: 01
20: 00	80: 01	140: 06	200: 07	260: 04	320: 00
30: 00	90: 02	150: 06	210: 06	270: 03	330: 00
40: 00	100: 03	160: 06	220: 06	280: 03	340: 00
50: 00	110: 03	170: 06	230: 06	290: 02	350: 00

Station: RIXENSART

Fréquence: 100.2 MHz

Position: 4°E33'33" 50°N42'12"

Puissance: 1000 W

Hauteur de l'antenne au-dessus du sol: 52 m

Diagramme directionnel de l'antenne:

0: 04	60: 00	120: 00	180: 01	240: 06	300: 07
10: 03	70: 00	130: 00	190: 02	250: 06	310: 06
20: 03	80: 00	140: 00	200: 03	260: 06	320: 06
30: 02	90: 00	150: 00	210: 03	270: 06	330: 06
40: 01	100: 00	160: 00	220: 04	280: 07	340: 06
50: 01	110: 00	170: 01	230: 05	290: 07	350: 05

Station: SAINT HUBERT

Fréquence: 100.2 MHz

Position: 5°E22'53" 50°N01'07"

Puissance: 50000 W

Hauteur de l'antenne au-dessus du sol: 30 m

Diagramme directionnel de l'antenne:

0: 03	60: 00	120: 03	180: 00	240: 00	300: 10
10: 03	70: 00	130: 03	190: 07	250: 00	310: 05
20: 03	80: 00	140: 03	200: 07	260: 07	320: 00
30: 03	90: 00	150: 00	210: 07	270: 07	330: 00
40: 00	100: 00	160: 00	220: 07	280: 10	340: 00
50: 00	110: 03	170: 00	230: 00	290: 10	350: 00

RESEAU 3

Station: SOIGNIES

Fréquence: 105.4 MHz

Position: 4°E01'40" 50°N35'32"

Puissance: 100 W

Hauteur de l'antenne au-dessus du sol: 35 m

Diagramme directionnel de l'antenne:

0: 06	60: 06	120: 03	180: 00	240: 00	300: 02
10: 06	70: 06	130: 03	190: 00	250: 00	310: 03
20: 06	80: 06	140: 02	200: 00	260: 00	320: 03
30: 07	90: 06	150: 01	210: 00	270: 00	330: 04
40: 07	100: 05	160: 01	220: 00	280: 01	340: 05
50: 07	110: 04	170: 00	230: 00	290: 01	350: 06

Station: TOURNAI

Fréquence: 93.6 MHz

Position: 3°E24'07" 50°N39'15"

Puissance: 400 W

Hauteur de l'antenne au-dessus du sol: 36 m

Diagramme directionnel de l'antenne:

0: 35	60: 27	120: 35	180: 08	240: 00	300: 19
10: 35	70: 30	130: 35	190: 05	250: 01	310: 30
20: 30	80: 30	140: 30	200: 03	260: 03	320: 30
30: 30	90: 35	150: 30	210: 01	270: 05	330: 35
40: 27	100: 35	160: 19	220: 00	280: 08	340: 35
50: 26	110: 35	170: 12	230: 00	290: 12	350: 35

Station: VIRTON

Fréquence: 104.8 MHz

Position: 5°E31'43" 49°N33'13"

Puissance: 2000 W

Hauteur de l'antenne au-dessus du sol: 35 m

Diagramme directionnel de l'antenne:

0: 03	60: 01	120: 13	180: 16	240: 16	300: 16
10: 02	70: 02	130: 16	190: 16	250: 16	310: 16
20: 01	80: 03	140: 16	200: 16	260: 16	320: 13
30: 00	90: 05	150: 16	210: 16	270: 16	330: 10
40: 00	100: 07	160: 16	220: 16	280: 16	340: 07
50: 00	110: 10	170: 16	230: 16	290: 16	350: 05

Station: WAREMME

Fréquence: 95.1 MHz

Position: 5°E15'47" 50°N41'02"

Puissance: 100 W

Hauteur de l'antenne au-dessus du sol: 36 m

Diagramme directionnel de l'antenne:

0: 00	60: 00	120: 00	180: 00	240: 00	300: 00
10: 00	70: 00	130: 00	190: 00	250: 00	310: 00
20: 00	80: 00	140: 00	200: 00	260: 00	320: 00
30: 00	90: 00	150: 00	210: 00	270: 00	330: 00
40: 00	100: 00	160: 00	220: 00	280: 00	340: 00
50: 00	110: 00	170: 00	230: 00	290: 00	350: 00

RESEAU 3

Station: WARNETON

Fréquence: 87.6 MHz

Position: 2°E56'45" 50°N45'00"

Puissance: 500 W

Hauteur de l'antenne au-dessus du sol: 26 m

Diagramme directionnel de l'antenne:

0: 30	60: 03	120: 03	180: 30	240: 30	300: 30
10: 30	70: 01	130: 05	190: 35	250: 30	310: 35
20: 19	80: 00	140: 08	200: 35	260: 27	320: 35
30: 12	90: 00	150: 12	210: 35	270: 26	330: 35
40: 08	100: 00	160: 19	220: 35	280: 27	340: 35
50: 05	110: 01	170: 30	230: 35	290: 30	350: 35
